

DVK2400-USB
(2.4GHz Transceiver Development Kit)
(for IEEE 802.15.4 Standard)

USER Manual

Revision History Hardware

Revision	Date	Description of Changes
V01	Jan. 2012	Initial release

Table of Contents

DVK2400-USB	1
USER Manual	1
1. Getting Started	3
1.1 Development Kit Contents	3
1.2 Optional Components	3
1.3 Software Installation	3
1.3.1 Different Software Tools	3
2. Instruction MCU2400-USB Board	4
2.1 Board Overview	4
2.2 Evaluation Board Variants	5
2.3 Connector Interface J1 (SPI Communication)	5
3. Disclaimer	6

1. Getting Started

1.1 Development Kit Contents

The development kit DVK2400-USB is delivered with all the components, documentations and software listed below:

- A pair of US2400-CS boards (50Ω Connector Board with SMA)
- A pair of MCU2400-USB (Microprocessor Board with USB interface)
- PC Software "RF-Tool 1.0" for RF testing
- PC Software "RF-Tool 2.0" for protocol debugging
- A pair of USB-Cables

1.2 Optional Components

The following components are not included in the DVK but can be ordered optionally:

- US2400-CU board (50Ω Connector Board with U.FL)
- US2400-A board (Chip antenna board)

Please see in section 2.2 "Evaluation Board Variants"

1.3 Software Installation


There is not installation process needed. The program is only one *.exe file that can be started directly. The program create a *.dll file therefore we recommend to copy this file into a dedicated folder of your choice before you start it.

1.3.1 Different Software Tools

- The RF-Tool 1.0 is dedicated for RF testing. You can toggle different channels, test and power modes.
- The RF-Tool 2.0 implement function like packet and protocol sniffer and is most useful for application protocol analyses and debugging.

For more information about the PC-Software please use the separated documentation:


- User Manual "RF-Tool 1.0" (PC-Software for RF Test -> E-Tool1.0))



- User Manual "RF-Tool 2.0" (PC Software for Protocol debugging), zur Zeit noch nicht verfügbar!

2. Instruction MCU2400-USB Board

2.1 Board Overview



Das Bild zeigt das MCU2400-USB Board:


- (1) Anschluss des RF-Evaluation Boards, nur im ausgeschalteten Zustand, d. h. vor anstecken des USB-Kabels.
- (2) USB Schnittstelle zum PC.
- (3) Status LEDs:
 - a) EIN – Leuchtet, sobald die Platine Strom hat
 - b) FUNK – Ist dauerhaft an, wenn ein Funkmodul angesteckt ist
 - c) LIVE – **Blinkt dauerhaft, während des Betriebs**
 - d) VDAI – Blinkt, wenn das Funk Modul Daten sendet
- (4) Reset Taste: Zur Zeit nicht Verfügung, Funktion erfolgt nur über ein Power-on-Reset

Hinweis:

Sollte bei der Platine die "LIVE" LED auch nach einem Hardware- und Software- Neustart nicht mehr blinken ist die Platine wahrscheinlich defekt.

2.2 Evaluation Board Variants



Type	Board Execution		Part No.
US2400-	CS	Connector version SMA	US2400-CS
	CU	Connector version U.FL	US2400-CU
	A	Antenna version	US2400-A



US2400-CS




US2400-CU



US2400-A

2.3 Connector Interface J1 (SPI Communication)

Pin	Pin Name	Description
1	RESETn	Global hardware reset pin, active low
2	Wake up	External wake up trigger
3	INT	Interrupt pin to microprocessor
4	MISO	Serial interface data output
5	MOSI	Serial interface data input
6	SCLK	Serial interface clock
7	SCL	Serial interface enable
8	GND	Ground
9	VDD	Power supply 2.4 - 3.6V



- For more detailed information, please refer to the latest US2400-EVB application note revision !

3. Disclaimer

Devices sold by Dacom West GmbH are covered by the warranty and patent indemnification provisions appearing in its Term of Sale. Dacom West GmbH makes no warranty, express, statutory, implied, or by description regarding the information set forth herein or regarding the freedom of the described devices from patent infringement. Dacom West GmbH reserves the right to change specifications and prices at any time and without notice. Therefore, prior to designing this product into a system, it is necessary to check with Dacom West GmbH for current information. This product is intended only for evaluation use.

The information furnished by Dacom West GmbH is believed to be correct and accurate. However, Dacom West GmbH shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interrupt of business or indirect, special incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data herein. No obligation or liability to recipient or any third party shall arise or flow out of Dacom rendering of technical or other services